

ElektroProg OUTDOOR

Prise programmable électronique

extérieure hebdomadaire



Merci de lire attentivement ce manuel avant toute utilisation et conserver le durant toute la durée de la garantie.

⚠ Ne branchez pas un appareil dont les caractéristiques dépassent 16 Ampères et/ou 3600W. Toujours veiller à ce que la prise de tout appareil soit entièrement insérée dans la prise de votre programmateur extérieur. Avant tout nettoyage de votre programmateur, le débrancher de la prise secteur puis l'essuyer avec un chiffon sec. Ne jamais l'immerger dans l'eau ou dans n'importe quel liquide. Vérifier régulièrement les branchements et le fonctionnement de vos appareils.

Définition des boutons de programmation / d'utilisation

- a-** MASTER CLEAR : effacer toutes vos données et programmes
- b-** RANDOM : fonction aléatoire
- c-** CLOCK : mise à jour date/heure avec les boutons WEEK, HOUR et MINUTE ou le mode 12/24H avec le bouton TIMER ou la fonction été avec le bouton ON/AUTO/OFF
- d-** TIMER : programmation des semaines, heures et minutes avec les boutons WEEK, HOUR et MINUTE ou le mode 12/24H avec le bouton CLOCK
- e-** ON / AUTO / OFF : sélectionner les modes de minuterie et la fonction été
- f-** WEEK : mise à jour de la semaine avec les boutons CLOCK et TIMER
- g-** HOUR : mise à jour de l'heure avec les boutons CLOCK et TIMER
- h-** MIN : mise à jour des minutes avec les boutons CLOCK et TIMER
- i-** RST / RCL : supprimer ou relancer un programme existant.

Caractéristiques

- 1-** Boîtier résistant à l'eau IP44
- 2-** 10 programmations actives possibles
- 3-** Choix de la fonction MANUEL
- 4-** Mode 12/24H
- 5-** Ecran LCD heure / minute / seconde
- 6-** Fonction Été
- 7-** Fonction Aléatoire
- 8-** 16 combinaisons de programmations journalières / hebdomadaires possibles

Initialisation

- 1-** Brancher votre programmateur dans la prise secteur 230V. Laisser recharger durant 14 heures minimum
- 2-** Appuyer sur le bouton MASTER CLEAR avec un crayon pour réinitialiser le programmateur
- 3-** Vous pouvez maintenant régler l'heure et la date
- 4-** Appuyer sur TIMER pour sélectionner votre fréquence d'arrêt. Puis faire de même avec les boutons HOUR et MINUTE.
- 5-** Une fois votre programmation terminée, appuyer sur le bouton CLOCK
- 6-** Répéter les étapes 1 à 4 pour installer les programmes 2 à 10.

Réglage date/heure

- 1-** Presser le bouton CLOCK puis simultanément le bouton WEEK, jusqu'au défilement du jour souhaité, puis relâcher. Faire de même avec les boutons HOUR et MIN, pour régler l'horaire souhaité
- 2-** En cas de problème, renouveler l'opération

Programmation

- 1-** Appuyer sur TIMER et relâcher. (une indication « ON-1 » apparaît à gauche)
- 2-** Appuyer sur WEEK pour sélectionner votre fréquence de mise en route. Puis faire de même avec les boutons HOUR et MINUTE.
- 3-** Appuyer de nouveau sur TIMER et relâcher. (une indication « OFF-1 » apparaît à gauche)

Mode ON/AUTO/OFF

Appuyez sur le bouton ON/AUTO/OFF pour sélectionner le mode de gestion choisi

- Soit « ON », votre programmateur est actif pour faire fonctionner un appareil directement sans programmation
- Soit « AUTO », votre programmateur ne fonctionnera que selon les sélections effectuées
- Soit « OFF », votre programmateur est totalement inactif

Fonction aléatoire

- 1-** Appuyez sur le bouton RANDOM. Une inscription **R** apparaît à droite de l'écran. La fonction aléatoire est activée.

- 2-** Lorsque cette fonction est activée, les programmes seront exécutés toutes les 30 minutes de façon aléatoire entre 18h00 et 06h00.

- 3-** Appuyez sur la touche RANDOM à nouveau pour annuler cette fonction.

Mode 12/24 heures

Maintenir CLOCK puis appuyer sur TIMER pour passer en mode 12 ou 24 heures.

Fonction été (mise à jour rapide de l'heure)

- 1-** Pour régler l'heure d'été : appuyez sur CLOCK et ON / AUTO / OFF simultanément. Une inscription « **S** » apparaît à droite de l'écran (heure d'été). L'horloge avance de 1 heure.
- 2-** Pour régler l'heure d'hiver : appuyez sur CLOCK et ON / AUTO / OFF simultanément. L'inscription « **S** » disparaît à droite de l'écran (heure d'hiver). L'horloge recule de 1 heure.



Pour une réponse personnalisée, utilisez notre chat en ligne sur notre site web www.scs-sentinel.com



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

ElektroProg OUTDOOR

Weekly electronic outdoor timer



Please read the following instructions carefully before connecting this timer to electrical appliances and keep during warranty limit.

⚠ Don't plug in an appliance where the load exceeds 16 Amp and / or 3600W. Always ensure the plug of any appliance is fully inserted into the timer outlet. If cleaning of the timer is required, remove from mains power and wipe timer with a dry cloth. Do not immerse timer in water or any other liquid. Heaters and similar appliances should never be left unattended during operation.

Keyboard definition

- a-** MASTER CLEAR: Clear all data in memory including current time and all programs.
- b-** RANDOM: Set or cancel random function.
- c-** CLOCK: Set current time combined with buttons WEEK, HOUR, MIN. Select 12 or 24 hour mode combined with button TIMER. Activate summertime function combined with button ON/AUTO/OFF.

- d-** TIMER: Set programs combined with buttons WEEK, HOUR, MIN. Select 12 or 24 hour mode combined with button CLOCK.
- e-** ON/AUTO/OFF: Select operating modes of timer.
- f-** WEEK: Set week combined with button CLOCK or TIMER.
- g-** HOUR: Set hour combined with button CLOCK or TIMER.
- h-** MIN: Set minute combined with button CLOCK or TIMER.
- i-** RST/RCL: Override programs or recall the overridden programs.

General features

- 1-** Water proof cover(IP44).
- 2-** 10 ON/OFF programs.
- 3-** ON/AUTO/MANUAL OFF modes selectable.
- 4-** 12/24 hour mode selectable.
- 5-** Large LCD display with hour/minute/second.
- 6-** Summertime function available.
- 7-** Random function
- 8-** 16 combinations of day or blocks of days available

Initial operation

- 1-** Plug the timer into a regular 230 Volts power outlet and turn the power on. Leave for approximately 14 hours to charge the memory back-up battery.
- 2-** Clear all current information by pressing MASTER CLEAR button with a sharp object such as a pen or pencil after charging.
- 3-** The timer is now ready to be set up for use.
- 4-** Press TIMER button again to finish the first OFF setting then set the time by pressing HOUR and MIN buttons.
- 5-** After completing settings, press CLOCK button. The timer is ready to operate.
- 6-** Repeat above 1 to 4 steps to set 2 to 10 programs

and enter into the first OFF setting. LCD shows OFF_1. Make the first OFF setting.

- 3-** When the mode is turned from MANUAL ON to AUTO, the timer will keep the setting of MANUAL ON until to the next timer setting.

disappears in LCD.

Setting current time

- 1-** Press CLOCK button and hold, simultaneously press WEEK button until the actual day is displayed. Then release. Continue by pressing HOUR or MIN button until the current hour or minute is displayed.
- 2-** In case of problem, repeat this setting operation.

ON/AUTO/OFF modes

Operating modes can't be changed during program settings.

- 1-** Press ON/AUTO/OFF button to revert the three modes in turn.
- 2-** The programs can only be executed in AUTO mode. When AUTO is selected, the timer operates as the programs. In MANUAL ON or MANUAL OFF mode all programs are ignored and the timer doesn't operate. When MANUAL ON mode is selected, power output is always ON. When MANUAL OFF mode is selected, power output is permanently off.

Setting programs

- 1-** Press TIMER button and release. LCD shows ON_1.
- 2-** Press WEEK button to set the day or block of days. Set the time by pressing HOUR and MIN button.
- 3-** Press TIMER button again to finish the first ON setting

Random function

- 1-** Press RANDOM button. LCD displays **R** (RANDOM). RANDOM function is activated.
- 2-** When this function is ON, the settings will be executed every 30 minutes between 6:00 PM and 6:00AM.
- 3-** Press the RANDOM button again to cancel this function.

12/24 hour mode

Hold CLOCK and press TIMER to switch to 12 or 24 hour mode.

Summertime function

- 1-** Press CLOCK and ON/AUTO/OFF simultaneously. LCD shows **S** (Summertime). Clock advances 1 hour.
- 2-** To revert to winter setting, press the two buttons again. Clock moves backward 1 hour. **S**

Specifications

Voltage : 230VAC, 50Hz
 Max Load : 16A, 3600W
 Min Setting Time : 1 Minute
 Operating temperature :
 -10 °C to +55 °C
 Battery backup :
 NiMH 1.2V >100hours



For an individual answer, use our online chat on our website
www.scs-sentinel.com