

PRISE PROGRAMMABLE HEBDOMADAIRE EXTERIEURE



Merci de lire attentivement ce manuel avant toute utilisation et conserver le durant toute la durée de la garantie.

⚠ Ne branchez pas un appareil dont les caractéristiques dépassent 16 Ampères et/ou 3600W. Toujours veiller à ce que la prise de tout appareil soit entièrement insérée dans la prise de votre programmeur extérieur. Avant tout nettoyage de votre programmeur, le débrancher de la prise secteur puis l'essuyer avec un chiffon sec. Ne jamais l'immerger dans l'eau ou dans n'importe quel liquide. Vérifier régulièrement les branchements et le fonctionnement de vos appareils.

d- TIMER : programmation des semaines, heures et minutes avec les boutons WEEK, HOUR et MINUTE ou le mode 12/24H avec le bouton CLOCK

e- ON / AUTO / OFF : sélectionner les modes de minuterie et la fonction été

f- WEEK : mise à jour de la semaine avec les boutons CLOCK et TIMER

g- HOUR : mise à jour de l'heure avec les boutons CLOCK et TIMER

h- MIN : mise à jour des minutes avec les boutons CLOCK et TIMER

i- RST / RCL : supprimer ou relancer un programme existant.

CARACTÉRISTIQUES

DEFINITION DES BOUTONS DE PROGRAMMATION / D'UTILISATION

a- MASTER CLEAR : effacer toutes vos données et programmes

b- RANDOM : fonction aléatoire

c- CLOCK : mise à jour date/heure avec les boutons WEEK, HOUR et MINUTE ou le mode 12/24H avec le bouton TIMER ou la fonction été avec le bouton ON/AUTO/OFF

1- Boîtier étanche IP44

2- 10 programmations actives possibles

3- Choix de la fonction MANUEL

4- Mode 12/24H

5- Ecran LCD heure / minute / seconde

6- Fonction Été

7- Fonction Aléatoire

8- 16 combinaisons de programmations journalières / hebdomadaires possibles

V.11-2015 ::: Ind. A



1

INITIALISATION

- 1- Brancher votre programmeur dans la prise secteur 230V. Laisser recharger durant 14 heures minimum
- 2- Appuyer sur le bouton MASTER CLEAR avec un crayon pour réinitialiser le programmeur
- 3- Vous pouvez maintenant régler l'heure et la date

REGLAGE HEURE ET DATE

- 1- Presser le bouton CLOCK puis simultanément le bouton WEEK, jusqu'au défilement du jour souhaité, puis relâcher. Faire de même avec les boutons HOUR et MIN, pour régler l'horaire souhaité
- 2- En cas de problème, renouveler l'opération

PROGRAMMATION

- 1- Appuyer sur TIMER et relâcher. (une indication « ON-1 » apparaît à gauche)
- 2- Appuyer sur WEEK pour sélectionner votre fréquence de mise en route. Puis faire de même avec les boutons HOUR et MINUTE.
- 3- Appuyer de nouveau sur TIMER et relâcher. (une indication « OFF-1 » apparaît à gauche)

4- Appuyer sur TIMER pour sélectionner votre fréquence d'arrêt. Puis faire de même avec les boutons HOUR et MINUTE.

5- Une fois votre programmation terminée, appuyer sur le bouton CLOCK

6- Répéter les étapes 1 à 4 pour installer les programmes 2 à 10.

MANUEL ON/AUTO/OFF

Appuyez sur le bouton ON/AUTO/OFF pour sélectionner le mode de gestion choisi

- Soit « ON », votre programmeur est actif pour faire fonctionner un appareil directement sans programmation

- Soit « AUTO », votre programmeur ne fonctionnera que selon les sélections effectuées

- Soit « OFF », votre programmeur est totalement inactif

FONCTION ALEATOIRE

- 1- Appuyez sur le bouton RANDOM. Une inscription **R** apparaît à droite de l'écran. La fonction aléatoire est activée.

2- Lorsque cette fonction est activée, les programmes seront exécutés toutes les 30 minutes de façon aléatoire entre 18h00 et 06h00.

3- Appuyez sur la touche RANDOM à nouveau pour annuler cette fonction.

MODE 12/24 HEURES

Appuyez sur CLOCK et TIMER simultanément pour activer l'affichage du temps entre le mode 12 et 24 heures.

FONCTION D'ETE (mise à jour rapide de l'heure)

1. Pour régler l'heure d'été : appuyez sur CLOCK et ON / AUTO / OFF simultanément. Une inscription « **S** » apparaît à droite de l'écran (heure d'été). L'horloge avance de 1 heure.
2. Pour régler l'heure d'hiver : appuyez sur CLOCK et ON / AUTO / OFF simultanément. L'inscription « **S** » disparaît à droite de l'écran (heure d'hiver). L'horloge recule de 1 heure.

CARACTÉRISTIQUES TECHNIQUES

Tension : 230VAC, 50Hz

Puissance maximum : 16A, 3600W

Temps de gestion : 1 Minute

Température d'utilisation : -10°C to +40 °C

Sauvegarde batterie : NiMH 1.2V >100hours

WEEKLY OUTDOOR TIMER



Please read the following instructions carefully before connecting this timer to electrical appliances and keep during warranty limit.

⚠ Don't plug in an appliance where the load exceeds 16 Amp and / or 3600W. Always ensure the plug of any appliance is fully inserted into the timer outlet. If cleaning of the timer is required, remove from mains power and wipe timer with a dry cloth. Do Not Immerse Timer In Water Or Any Other Liquid. Heaters and similar appliances should never be left unattended during operation.

- d- TIMER:** Set programs combined with buttons WEEK, HOUR, MIN. Select 12 or 24 hour mode combined with button CLOCK.
- e- ON/AUTO/OFF:** Select operating modes of timer.
- f- WEEK:** Set week combined with button CLOCK or TIMER.
- g- HOUR:** Set hour combined with button CLOCK or TIMER.
- h- MIN:** Set minute combined with button CLOCK or TIMER.
- i- RST/RCL:** Override programs or recall the overridden programs.

GENERAL FEATURES

- 1- Water proof cover(IP44).
- 2- 10 ON/OFF programs.
- 3- ON/AUTO/MANUAL OFF modes selectable.
- 4- 12/24 hour mode selectable.
- 5- Large LCD display with hour/minute/second.
- 6- Summertime function available.
- 7- Random function
- 8- 16 combinations of day or blocks of days available

KEYBOARD DEFINITION

- a- MASTER CLEAR:** Clear all data in memory including current time and all programs.
- b- RANDOM:** Set or cancel random function.
- c- CLOCK:** Set current time combined with buttons WEEK, HOUR, MIN. Select 12 or 24 hour mode combined with button TIMER. Activate summertime function combined with button ON/AUTO/OFF.

V.05-2015 ::: Ind. A



4

INITIAL OPERATION

- 1- Plug the timer into a regular 230 Volts power outlet and turn the power on. Leave for approximately 14 hours to charge the memory back-up battery.
- 2- Clear all current information by pressing MASTER CLEAR button with a pen or pencil after charging.
- 3- The timer is now ready to be set up for use.

SETTING CURRENT TIME

- 1- Press CLOCK button and hold, simultaneously press WEEK button until the actual day is displayed. Then release. Continue by pressing HOUR or MIN button until the current hour or minute is displayed.
- 2- In case of problem, repeat this setting operation.

SETTING PROGRAMS

- 1- Press TIMER button and release. LCD shows ON_1.
- 2- Press WEEK button to set the day or block of days. Set the time by pressing HOUR and MIN button.
- 3- Press TIMER button again to finish the first ON setting and enter into the first OFF setting.

LCD shows OFF_1. Make the first OFF setting.

- 4- Press TIMER button again to finish the first OFF setting then set the time by pressing HOUR and MIN buttons.
- 5- After completing settings, press CLOCK button. The timer is ready to operate.
- 6- Repeat above 1 to 4 steps to set 2 to 10 programs

MANUAL ON/AUTO/MANUAL OFF SETTING

Operating modes can't be changed during program settings.

- 1- Press ON/AUTO/OFF button to revert the three modes in turn.
- 2- The programs can only be executed in AUTO mode. When AUTO is selected, the timer operates as the programs. In MANUAL ON or MANUAL OFF mode all programs are ignored and the timer doesn't operate. When MANUAL ON mode is selected, power output is always ON. When MANUAL OFF mode is selected, power output is permanently off.
- 3- When the mode is turned from MANUAL ON to AUTO, the timer will keep the setting of MANUAL ON until to the next timer setting.

RANDOM FUNCTION

- 1- Press RANDOM button. LCD displays R(RANDOM). RANDOM function is activated.
- 2- When this function is ON, the settings will be executed every 30 minutes between 6:00 PM and 6:00AM.
- 3- Press the RANDOM button again to cancel this function.

12/24 HOUR MODE

Press CLOCK and TIMER simultaneously to turn the time display between 12 and 24 hour mode.

SUMMERTIME FUNCTION

- 1- Press CLOCK and ON/AUTO/OFF simultaneously. LCD shows S (Summertime). Clock advances 1 hour.
- 2- To revert to winter setting, press the two buttons again. Clock moves backward 1 hour. S disappears in LCD.

SPECIFICATIONS

Voltage : 230VAC, 50Hz
Max Load : 16A, 3600W
Min Setting Time : 1 Minute
Operating temperature :
-10 oC to +40 oC
Battery backup :
NiMH 1.2V >100hours