
# TÉLÉCOMMANDE



La configuration des télécommandes ne suffit pas à faire fonctionner le système correctement. Vous devez effectuer l'apprentissage du système.

### **OUVRIR LES PORTES ENTIÈREMENT**

- 1. Prenez une télécommande et tenez-vous devant l'armoire électrique ouverte.
- 2. Localiser RF-LEARN et la LED bleue.
- 3. Appuyez sur la touche RF-LEARN pendant 2 secondes puis relâchez. La LED bleue s'allume.
- 4. Appuyez sur un bouton de la télécommande, la LED bleue clignote pendant 9 secondes.
- 5. La LED bleue s'éteint: votre télécommande est programmée.
- 6. Appuyez sur une touche pour le fonctionnement des deux vantaux et sur le bouton B pour le fonctionnement d'un seul vantail.
- 7. Le réglage de fonctionnement A et B bouton suivra le réglage du commutateur DIP sur la carte de circuit imprimé de la boîte de contrôle.



### Déprogrammation des télécommandes et des accessoires radio Cette procédure efface toutes programmations radio

- 1. Appuyez sur RF-LEARN et maintenez appuyé pendant 10 secondes
- 2. La LED bleue s'allume
- 3. La LED bleue s'éteint
- 4. 100% des accessoires radio sont effacés

## REMOTE CONTROL




Setting up the remote controls does not suffice to make the system function correctly.

You must perform the system learning

### OPENING THE GATES (the complete gate)

- 1. Take a remote control and Stand in front of the open electrical cabinet.
- 2. Locate RF-LEARN and BLUELED.
- 3. Press key RF-LEARN for 2 seconds then release. BLUELED lights up.
- 4. Press A button on the remote, BLUELED goes out and lights up again for 9 seconds.
- 5. BLUELED goes out: your remote control is programmed.
- 6. Press A button for two leaves operation and B button for single leaf operation.
- 7. The operation setting of A & B button will follow the dip switch setting on the PCBA of control box.



## DEPROGRAMMING THE REMOTE CONTROLS and radio accessories This procedure erases all radio programming

- 1. Press RF-LEARN and hold down for 10 seconds
- 2. BLUELED lights up
- 3. BLUELED goes out
- 4. 100% of the radio accessories are closed