

# PROGRAMMATEUR MÉCANIQUE 24H



## FONCTIONNEMENT

1. Branchez le programmeur et connectez l'appareil destiné à être programmé (lampe etc...).
2. Tournez le disque dans le sens horaire (flèche) jusqu'à ce que vous pointiez avec le triangle noir, l'heure actuelle.
3. Enfoncez les fiches noires correspondant aux périodes de fonctionnement souhaitées (15 min. Pour une tranche réglable pendant 24 heures).

Attention: cet appareil fonctionne uniquement connecté sur secteur.

Tension: 220-240V 50Hz

Charge maxi : 16A 3500W

## DÉCLARATION DE GARANTIE

**GARANTIE 1 AN**

PAR COURRIER

**SCS SENTINEL - Service commande  
Rte de St Symphorien - BP 69  
85130 Les Landes Génusson (FRANCE)**

PAR INTERNET

**scs-laboutique.com**

N'oubliez pas d'enregistrer votre garantie  **dans le mois suivant votre achat.** Conservez soigneusement votre justificatif d'achat. (photocopie ticket de caisse ou facture). Il vous sera demandé pour faire valoir la garantie.

## PROGRAMMATEUR MÉCANIQUE 24H

Code barre (numéro à 13 chiffres) .....

N° lot (à côté du code barre) : .....

### LIEU D'ACHAT

enseigne : ..... date achat : .....

ville : ..... CP : .....

### VOUS

nom : ..... prénom : .....

tél. : ..... email : .....

ville : ..... CP : .....

### INSTALLATEUR

particulier  professionnel

société : .....

siret : .....



# WARRANTY DECLARATION

WARRANTY 1 YEAR

BY MAIL

**SCS SENTINEL** - Service commande  
Rte de St Symphorien - BP 69  
85130 Les Landes Génusson (FRANCE)

BY WEBSITE

**scs-laboutique.com**

TO SEND AT LEAST 1 MONTH  
AFTER PURCHASING.

Please keep a proof of  
purchase.

## 24H MECHANICAL PROGRAMMER

Gencod (13 numbers) : .....

Batch number (close to gencod) : .....

### PURCHASE LOCATION

Company : ..... Date of purchase : .....

City : ..... ZIP code : .....

### YOU

Name : ..... Surname : .....

Phone : ..... email : .....

City : ..... ZIP code : .....

### INSTALLATION BY

Person  Company

Name : .....

ID code : .....

user instructions

EN

# 24H MECHANICAL PROGRAMMER



### OPERATION

1. Plug in socket, and connect this facility with the home appliance.
2. Turn the disc following the arrow 's' direction till the mark pointing to the current time.
3. Push down the joint slices according to the working duration of home appliances as expected. (15 min. For one slice, adjustable for 24 hr.)

Caution: It can only be used within the power

Voltage: 220-240V 50Hz

Maxload: 16A 3500W



V.06-2015 ::: Ind. A

