

MecaProg

indoor

Prise programmable
mécanique intérieure
journalière



Fonctionnement

1. Branchez le programmeur et connectez l'appareil destiné à être programmé (lampe etc...).
2. Tournez le disque dans le sens horaire (flèche) jusqu'à ce que vous pointiez avec le triangle noir sur l'heure actuelle.
3. Enfoncez les fiches noires correspondant aux périodes de fonctionnement souhaitées (15 min. pour une tranche réglable pendant 24 heures).

Attention: cet appareil fonctionne uniquement connecté sur secteur.

Tension : 220-240V 50Hz

Charge maxi : 16A 3500W

MecaProg

indoor
Daily mechanical
indoor timer



Operation

1. Plug in socket, and connect this facility with the home appliance.
2. Turn the disc following the arrow 's direction till the mark pointing to the current time.
3. Push down the joint slices according to the working duration of home appliance as expected.
(15 min. for one slice, adjustable for 24 hr.)

Caution: It can only be used within the power

Voltage: 220-240V 50Hz

Maxload: 16A 3500W